



We want to be with you every step of the way. So much so, that we've created an exclusive Spotify playlist for you and your renovation.
Let the rhythm play!

APPLICATION GUIDE
STEP BY STEP



If Gaudi had this guide, the Sagrada Familia would have been finished a looong time ago.



**IMAGINE IT.
CREATE IT.
ENJOY IT.**



RENOVATION
WITHOUT
BUILDING WORK

You've been picturing it for a while.
And now it's time to get creative!

Don't worry because this kit contains eveeeverything you need to do the renovation totally by yourself, the one you've been dreaming of for so long.

We could tell you that you'll be enjoying that new nook in your home "in the blink of an eye" or "in no time at all" , but the truth is, with Smartcret, we don't even have to mention it.

Just enjoy the ride and the joy of the finished product . We'll take care of the rest.

We'll guide you through the step-by-step process for your renovation.

Let's get started!

www.smartcret.com

01

TIME TO CLEAN UP!



For the finished product to be beautiful and perfect, it's essential that the surface be free of dust and grease.

So, let's cleeeean.

Then, take the protective adhesive tape and outline the surface where you'll be applying the microcement.

***Important:** If the substrate is not stable and/or shows cracks or chipping, repair it. If there is excessive damp or mildew in the substrate, make it dampfree.



02

CHOOSE BETWEEN

02A

Absorbent surfaces
(Drywall, plaster, etc.)

02B

Non-absorbent surfaces
(Marble, terrazzo, tiles, etc.)

03

THE HEART OF THE RENOVATION



Do you remember the dance from the "Macarena"? Well, stir to the rhythm of the song, with the help of the **Smart Base** spatula. Then, dip the **Smart Roller** for microcement into the **Smart Base** and roll it onto a section of the surface, using the trowel to smooth it down.

Then, **apply 2 layers with the roller and the trowel** and remove the adhesive tape.

Let it dry for **six hours** in between each layer for it to dry properly.

Sand the surface with **sandpaper, grain size 40***. You'll see the sandpaper grain on the Velcro. Just attach it to the sanding glove and start sanding, sanding, and sanding.

*If you have purchased our toolkit, you will find the sandpaper there :)



04

LIKE PUDDING, SHALL WE HAVE SECONDS?



Dance again and mix **Smart Liso** with the spatula!

Place the protective tape back on. Dip the **Smart Roller** for microcement into the **Smart Liso** and roll it onto a section of the surface, using the trowel to smooth it down. Apply **2 layers with the roller and trowel**.

Remove the tape and **let it dry for 6 hours** in between each layer.

Sand after each layer with **sandpaper, grain size 220**.



05

PROTECTION ABOVE ALL



When you ordered, you chose the finish you wanted (matte or satin), but also so much more: **Smart Varnish** will protect the surfaces to make them look perfect.

24h after applying the last layer of **Smart Liso**, place the adhesive tape on the surface. Apply **3 layers of Smart Varnish** in a single day and allow each layer to dry for **4 hours** in between each application.

For extra protection: apply 4 coats in damp areas such as bathrooms and/or floors with heavy foot traffic.

We recommend sanding the first and second layers with **sandpaper, grain size 400**.

***Important:** We recommend waiting for 7 days to allow the varnish to reach its peak performance.

****All sandpaper grits mentioned in this step-by-step guide are for manual sanding (not machine sanding).**

Well bonded surfaces



It's time to prepare the surface to make sure that the microcement adheres properly. And for that, we have **Smart Primer ABS**.

Take the roller and the handle, attach them, and apply **one layer of Smart Primer ABS** (pour the product into a tray for added convenience).

Wait for approximately 30 minutes for it to dry, and clean the roller immediately to prolong its lifespan.

Say goodbye to the grout joints



Take **Smart Jointer** and fill the grout joints in between the tiles with **one layer**. Use a spatula or trowel.

Go for a jog, sleep, or do that chore you've been putting off while you wait for it to **dry for 24 hours**.

Then, sand the surface with sandpaper, grain size 40*. You'll see the sandpaper grain on the velcro. Just attach it to the sanding glove and start sanding, sanding, and sanding.

*If you have purchased our toolkit, you'll find the glove there :)

Unity is strength



It's time to prepare the surface to make sure the microcement adheres properly. And for that, we have **Smart Primer GRIP**.

Use the spatula to mix the product by hand.

Take the roller and the handle, attach them, and apply **one layer of Smart Primer GRIP** (pour the product into a tray for added convenience).

Wait for 2-4 hours for it to dry, and clean the roller with water immediately after use to prolong its lifespan.

IMAGINE IT. CREATE IT. ENJOY IT.

And voila! You've just renovated that nook in your home easily in just a few days.

Now, enjoy it, make the most of it, and if you feel like it, unveil your work to the world :)

At Smartcret, we can't wait to see the finished result.

Icon guide

